

MODEL CODES

EDITION III




Linde Hydraulics Corporation

5089 West Western Reserve Road Canfield, Ohio 44406

Telephone: (330) 533-6801 Fax: (330) 533-2091

Model Codes for M-Series Open Loop Pumps



NOTES: (1) If codes are not used, insert the letter "X".

- (2) If a unit is a **special execution**, insert "S" at the end of the code description.
- (3) Standard MPR includes both, LS and DR. When used as LS, DR acts as pressure cut off. When used as DR, LS is blocked.